



## **ADDENDUM**

**All Grant Duowave Cylinders  
All Grant Monowave Cylinders**

- 1. All cylinder connections should be made using only the supplied fittings – failure to do so will invalidate any warranty**
- 2. The Temperature and Pressure Relief Valve connection should not be used for any other purpose**
- 3. Please ensure that no valve is fitted between the expansion valve and the cylinder**
- 4. The discharge pipe arrangement (Tundish), drain valves, motorised valves, etc must be positioned away from any electrical components (thermostats, etc)**

Please do not remove this sheet from the installation manual.

If you have any questions relating to this sheet,  
please call 01380 736920 .

Neil Sawers  
Technical Manager  
Grant Engineering (UK) Ltd